

Assembly instructions – Lifting Anchor

Required tools:

- Drill
- Forstner bit Ø 40 mm
- (Cordless) screwdriver

Requirements


- To be carried out by experts only.
- Minimum material width: 120 mm
- Minimum material thickness: 60 mm

1. Drill a hole in the middle of the wood using a Forstner bit. (same distance from the sides)



Assembly instructions – Lifting Anchor

1.1. Drill through if the material is < 80 mm thick.



1.2. Drill to a depth of 80 mm if the material is > 80 mm thick.



2. Thoroughly remove swarf.

Assembly instructions – Lifting Anchor

3. Press the lifting anchor into the hole.



4. Align the top edge of the sleeve so that it is flush with the top edge of the hole.



Assembly instructions – Lifting Anchor

5. Screw in the eight screws supplied.



Assembly instructions – Lifting Anchor

6. Test whether the ball supporting bolt can be properly inserted into the sleeve and engages without any problems. The ball supporting bolt must be able to turn on its own axis, but not pulled out again.



If you are not familiar with how this product is used, and particularly with the product's intended use, please contact our Application Technology department (technik@eurotec.team).